




# Beta 9566T

## Istruzioni di montaggio - Assembly Instructions




- Leggere con attenzione le istruzioni - Please read the instructions manual carefully
- Assemblare con cura secondo istruzioni - Please assemble it carefully according to the instructions
- Verificare che tutte le parti siano integre - Please check that all partes are undamaged




# **Beta 9566S/3**

## Istruzioni di montaggio - Installation Manual

### ISTRUZIONI - INSTRUCTIONS




1




2

Rimuovere il tappo nero e posizionare l'anello sulla base cromata prima di installare il sollevatore a gas -  
Remove the black cap and place the ring on the chrome base before installing the gas lift



3



### ACCESSORI - ACCESSORIES

Seduta - Seat



x1

Sistema di regolazione  
seduta - seat adjustment  
system



x1

Sollevatore a gas  
- gas lift



x1

Viti - screws



x4

Anello - ring



x1

Base cromata -  
chrome base



x1

Brugola - key wrench



x1



**BETA UTENSILI S.p.A. (HEADQUARTER)**

via Alessandro Volta, 18  
20845 Sovico (MB) ITALY  
Tel. +39 039.2077.1 - Fax +39 039.2010742  
[www.beta-tools.com](http://www.beta-tools.com)

**BETA BENELUX B.V.**

Belder 9-B  
4704 RK Roosendaal - NEDERLAND  
Tel. +31.1655.34761 - Fax. +31.1655.34791  
[www.betabenelux.nl](http://www.betabenelux.nl) - [info@betabenelux.nl](mailto:info@betabenelux.nl)

**BETA DO BRASIL COMERCIO DE MAQUINAS  
E FERRAMENTAS LTDA**

Estrada Velha de Cotia, 480  
Jardim Passargada- CEP: 06712-430  
Cotia São Paulo - BRASIL  
Tel: +55.11.3721.5065 - Fax: +55.11.3721.9353  
[www.betabrasil.com.br](http://www.betabrasil.com.br) - [betabrasil@betabrasil.com.br](mailto:betabrasil@betabrasil.com.br)

**BETA INDUSTRIAL PRODUCTS TRADING  
(SHANGHAI) CO. LTD**

Room 902, Building 2  
No.2388 Chenhang RD, Minhang District  
Shanghai, 201114, CHINA  
Tel: 0086-21-58182000 - Fax: 0086-21-60251399  
Hotline:4006-19-18-19  
[www.beta-tools.com.cn](http://www.beta-tools.com.cn) - [info@beta-tools.net](mailto:info@beta-tools.net)

**BETA FRANCE SAS**

163 Avenue des Tamaris  
Z.I. Athélia 4  
13600 La Ciotat - FRANCE  
Tel. +33.491.364010  
[beta.france@beta-tools.com](mailto:beta.france@beta-tools.com)

**BETAMAX KFT**

Megyeri út 51  
H 1044 Budapest - HUNGARY  
Tel. +36.1.2702700  
[www.betamax.hu](http://www.betamax.hu) - [info@betamax.hu](mailto:info@betamax.hu)

**BETA IBERIA S.L.**

Av Castilla 26, Nave 4  
28830 San Fernando De Henares - Madrid  
ESPAÑA  
Tel. +34.91.6778340 - Fax +34.91.6758558  
[beta.iberia@beta-tools.com](mailto:beta.iberia@beta-tools.com)

**BETA POLSKA SP. Z O.O.**

72-002 DOŁUJE, SKARBIMIERZYCE  
ul. Wiosenna 12 - POLSKA  
Tel. +48.91.48.08.227 / +48.91.48.08.236  
Fax: +48.91.48.08.219  
[www.beta-polska.pl](http://www.beta-polska.pl) - [bok@beta-polska.pl](mailto:bok@beta-polska.pl)

**BETA TOOLS (UK) LTD**

Unit-D Horton Enterprise Park  
Hortonwood,50  
Telford - Shropshire - TF1 7GZ  
GREAT BRITAIN  
Tel. +44.1952.677977 - Fax. +44.1952.677545  
[www.beta-tools.co.uk](http://www.beta-tools.co.uk) - [beta.uk@beta-tools.com](mailto:beta.uk@beta-tools.com)

**BETA TOOLS USA**

210 Chestnut St.  
Columbia, PA 17512 - USA  
Tel. +1.717.449.5044 - Fax. +1.717-449-5244  
[www.betatoolsusa.com](http://www.betatoolsusa.com)  
[customerserviceusa@betatoolsusa.com](mailto:customerserviceusa@betatoolsusa.com)