

1569/B

Assortment of tools for removing and installing silent blocks, oil seals and wheel bearings

Diameter: 14÷32 mm

- Direct extraction with wrench
- User-friendly, no pneumatic or hydraulic tools required
- Can be used with Beta kit 1569/A

Kit contents:

- threaded bars, washers and bushings for diameters 14÷32 mm

