




















6600 M/657

sada 17 nástrojů, s háky bez panelu

		art.
	066000657	6600 M/657



1000		1000	1
1001		1001	1
1002		1002	1
1003		1003	1
1004		1004	1
1005		1005	1
1006		1006	1
1007		1007	1
1008		1008	1
1009		1009	1
1010		1010	1
1011		1011	1
1012		1012	1
1013		1013	1
1014		1014	1
1015		1015	1
1016		1016	1
1017		1017	1