


UNI 6742 DIN 3112

- De schuifhendel kan van links naar rechts in de gewenste positie worden vastgezet.
- Een veiligheidspal voorkomt dat de hendel eruit schiet, waardoor ongelukken worden voorkomen.
- Drievoudige maatmarkering op de kop.

	art.	M mm	L mm	H mm	Ø mm	P mm	P1 mm	g
009500006	950 6	6	210	145	10,1	14,5	5	98
009500007	950 7	7	212	145	11,2	15,5	6	100
009500008	950 8	8	220	160	12,4	18,5	7	140
009500009	950 9	9	223	160	13,5	19,5	8	142
009500010	950 10	10	230	160	14,9	20,5	8,5	172
009500011	950 11	11	233	160	16,1	21,5	9	176
009500012	950 12	12	240	175	17,5	22,5	9,5	228
009500013	950 13	13	244	175	19,7	23,5	10,5	233
009500014	950 14	14	250	190	20,1	24,5	11,5	289
009500015	950 15	15	254	190	21,5	24,5	12	307
009500016	950 16	16	260	200	22,7	25,5	12,5	414
009500017	950 17	17	264	200	24,1	26,5	13	436
009500019	950 19	19	274	230	26,6	28,5	14,5	553
009500022	950 22	22	290	230	29,9	31,5	16	797
009500024	950 24	24	300	320	32,2	35,5	18	976
009500027	950 27	27	314	370	36,2	41,5	21	1265

