

**9742 - Contact
Cleaner**

Cleaner for electric and electronic contacts

Useful for cleaning and cleansing electronic contacts, circuits and electrical components in general.
Its non-thick consistency allows uniform, quick distribution on treated surfaces, removing grease and dirt, without leaving oily residue.
Evaporates quickly. Does not damage plastics and rubber.

DIRECTION FOR USE: Apply product at short intervals.
Clean with a dry cloth.

	art.	ml
097420040	9742 (1)	400
097421040	9742 (2)	400
097422040	9742 (3)	400

