

Beta

C39-8/R

039000043

** XX=Key codes from F 00 to F 19

Ricambi / Spare parts

		
①	039000525	1
②	0390010XX	1**
③	039000528	1
④	024990220	1 (1 coppia / 1pair)
⑤	039000521	1*
⑥	039000522	1*
⑦	050000103	1
⑧	050000102	1
⑨	050000101	1
⑩	032000502	1
⑪	024990223	1
⑫	039000527	1 (1 coppia / 1pair)
⑬	039000526	1

