



 **Beta**

RSC50 PM

050001302

Ricambi / Spare parts

	
① 050001916	1
② 0500020XX	1*

*XX=Key codes from F00 to F19

