

**921BA**
**sparkproof bi-hex sockets**



art.	mm						
009210808	921BA 8	8	24,0	40	19	15,0	77
009210809	921BA 9	9	24,0	40	19	16,0	77
009210810	921BA 10	10	16,5	40	19	24,0	77
009210811	921BA 11	11	17,5	40	19	24,0	76
009210812	921BA 12	12	18,5	40	19	24,0	74
009210813	921BA 13	13	19,5	40	19	24,0	75
009210814	921BA 14	14	20,0	40	19	24,0	77
009210815	921BA 15	15	21,5	40	19	24,0	86
009210816	921BA 16	16	24,0	40	19	24,5	87
009210817	921BA 17	17	25,0	40	22	25,0	88
009210818	921BA 18	18	25,0	40	22	25,0	97
009210819	921BA 19	19	28,0	42	22	27,0	109
009210820	921BA 20	20	29,0	42	22	28,0	124
009210821	921BA 21	21	30,0	43	22	30,0	143
009210822	921BA 22	22	30,5	43	22	30,0	145
009210824	921BA 24	24	34,0	43	22	31,0	173
009210825	921BA 25	25	36,0	43	22	33,0	200
009210826	921BA 26	26	37,5	43	22	34,0	220
009210827	921BA 27	27	37,5	45	22	34,0	238
009210828	921BA 28	28	38,9	46	22	36,0	260
009210830	921BA 30	30	41,5	46	22	37,5	290
009210832	921BA 32	32	43,5	46	22	41,5	305



Without adequate in use beta-tools should not be used in areas where explosive atmosphere is present or where it is likely to be formed.  
 Condizioni per l'uso nei luoghi dove è presente o può formarsi un'atmosfera esplosiva.  
 Beta sparkproof tools cannot be used in areas where explosive atmosphere is present or where it is likely to be formed.  
 Appareils non utilisés dans les zones où est présente ou peut se former une atmosphère explosive.



Without adequate in use beta-tools should not be used in areas where explosive atmosphere is present or where it is likely to be formed.  
 Condizioni per l'uso nei luoghi dove è presente o può formarsi un'atmosfera esplosiva.  
 Beta sparkproof tools cannot be used in areas where explosive atmosphere is present or where it is likely to be formed.  
 Appareils non utilisés dans les zones où est présente ou peut se former une atmosphère explosive.

